

3.5.2 단자 설명

10.1

		L1 · L2 · L3 AC230C L1 · L2 · L3																
L1 · L2 · L3		<table border="1"> <tr> <td></td> <td>MR-J2S-10B ~ 70B</td> <td>MR-J2S-100B ~ 22KB</td> <td>MR-J2S-10B1 ~ 40B1</td> </tr> <tr> <td>AC200~230V, 50/60Hz</td> <td colspan="3">L1 · L2 · L3</td> </tr> <tr> <td>AC230V, 50/60Hz</td> <td>L1 · L2</td> <td></td> <td></td> </tr> <tr> <td>AC100~120V, 50/60Hz</td> <td></td> <td></td> <td>L1 · L2</td> </tr> </table>		MR-J2S-10B ~ 70B	MR-J2S-100B ~ 22KB	MR-J2S-10B1 ~ 40B1	AC200~230V, 50/60Hz	L1 · L2 · L3			AC230V, 50/60Hz	L1 · L2			AC100~120V, 50/60Hz			L1 · L2
	MR-J2S-10B ~ 70B	MR-J2S-100B ~ 22KB	MR-J2S-10B1 ~ 40B1															
AC200~230V, 50/60Hz	L1 · L2 · L3																	
AC230V, 50/60Hz	L1 · L2																	
AC100~120V, 50/60Hz			L1 · L2															
U · V · W		(U · V · W)																
L11 · L21		<table border="1"> <tr> <td></td> <td>MR-J2S-10B ~ 700B</td> <td>MR-J2S-10B1 ~ 40B1</td> </tr> <tr> <td>AC200~230V</td> <td colspan="2">L11 · L21</td> </tr> <tr> <td>AC100~120V</td> <td></td> <td>L11 · L21</td> </tr> </table>		MR-J2S-10B ~ 700B	MR-J2S-10B1 ~ 40B1	AC200~230V	L11 · L21		AC100~120V		L11 · L21							
	MR-J2S-10B ~ 700B	MR-J2S-10B1 ~ 40B1																
AC200~230V	L11 · L21																	
AC100~120V		L11 · L21																
P1	DC	<p>DC, P-P1</p> <p>()</p> <p>DC, P-P1 ()</p> <p>P-P1 DC ()</p> <p>MR-J2S-11KB~22KB (12.2.4)</p>																
P · C · D		<p>MR-J2S-350B</p> <p>() ,P-D</p> <p>,P-D P C</p> <p>MR-J2S-500B · 700B</p> <p>MR-J2S-500B · 700B D</p> <p>() ,P C</p> <p>,P C P C</p> <p>MR-J2S-11KB~22KB</p> <p>MR-J2S-11KB~22KB D</p> <p>C</p> <p>12.1.1</p>																
N		,P-N MR-J2S-350B 11.1.2, 12.1.3																
⊕	(PE)	(PE)																